

# Trouble Shooting



No visible bubbles	<ul style="list-style-type: none"> <li>• Check power source</li> <li>• Remove rubber plug</li> </ul>
Light blinks when operating unit	<ul style="list-style-type: none"> <li>• Low battery indicator</li> <li>• Charge Unit battery soon</li> </ul>
Low PPM levels when tested with H2 Blue Drops	<ul style="list-style-type: none"> <li>• Allow 7 days to break-in</li> <li>• Keep generator wet.</li> <li>• Do not stir after each drop</li> <li>• Fill bottle to maximum</li> </ul>
Wetness in Generator	<ul style="list-style-type: none"> <li>• Units are shipped wet</li> </ul>
Battery not charging	<ul style="list-style-type: none"> <li>• Check if Plug is defective</li> </ul>
Unit is leaking water	<ul style="list-style-type: none"> <li>• Check all seals, tighten lid</li> <li>• Empty waste chamber</li> <li>• Check if missing washers</li> </ul>
Bottle has odor or Unit makes less gas	<ul style="list-style-type: none"> <li>• Run Cleaning cycle</li> <li>• Taste/smell water source</li> </ul>
Unit stopped working	<ul style="list-style-type: none"> <li>• Call For Warranty Support</li> </ul>
Glass bottle broke	<ul style="list-style-type: none"> <li>• Call to order replacement</li> </ul>
Unit stops charging	<ul style="list-style-type: none"> <li>• Test Cable, Call For Support</li> </ul>
Water leaks at top Rim of bottle lid	<ul style="list-style-type: none"> <li>• Leave air space between water level and bottle lid</li> </ul>
For All Other or Any Unsolved Problem Call For Support	

**CALL US: 860-806-9997**

**7 days a week 9 am - 9 pm EST**

**Or visit website: [www.H2WaterforLife.com](http://www.H2WaterforLife.com)**

# H2WaterForLife

Global Leader  
in Hydrogen



## H2 USB Sport MAXX

*You're Going To Like  
The Way You Feel!*



## H2WaterForLife

Email: [info@H2WaterforLife.com](mailto:info@H2WaterforLife.com) Tel: 860-806-9997

[www.H2WaterForLife.com](http://www.H2WaterForLife.com)

124 Litchfield Rd. Morris, Ct. 06763 USA

*Most Advanced, Safe and Effective  
Hydrogen Water Making Technology*

**WARRANTY: One Year Parts & Labor**

- Disclaimer: Product is not intended to diagnose, cure, treat or prevent disease. Seek medical advice if ill.**
- Never operate Generator without water in the bottle.
  - Keep USB Port sealed by plugging its cover back in.
  - Generator is shipped wet, remove plug before using.
  - Operate only with any type of potable drinking water.
  - Not for use with hot, carbonated or other beverages.
  - Always keep Generator moist by keeping Lid on.
  - Battery is charged when LED light stops blinking.
  - Do not place Generator unit in a refrigerator or cooler.
  - Do not soak or submerge Generator Unit under water.
  - Try to drink within 10 minutes of making H2 water.
  - Do not store to drink later, it will dissipate quickly.
  - To share water pour into a glass and drink in minutes.
  - Check waste chamber daily and empty any water there.
  - Use cold or room temperature water. Never use ice.
  - Doing more than 2 timed cycles may cause leaking and will not increase hydrogen gas PPM saturation levels.
  - Battery has limited life span and to prolong its life, drain the battery completely before recharging it.
  - Keep away from children, Pets, Heat and Flames.
  - Do not pull cable from wire or plug with wet hands.
  - Call for product support if you have any questions.

- To Set Up:**
1. Wash glass bottle and lid with soap and warm water.
  2. Unscrew Generator cover and remove and dispose rubber plug.
  3. Gently twist bottle on to generator track and tighten snug to seal.
  4. With bottle attached rinse out inside Generator with warm water.
  5. Fill bottle with clean drinking water up to bottle threads.
  6. Cap bottle with lid and insert USB cable into Unit USB Port.
  7. Insert other cable end to power plug and plug it into wall outlet.
  8. Charge battery 2 or more hours before operating machine.
  9. Battery charge will automatically shut off when fully charged.
- Power Button:**
- Power toggle switch has 3 positions with a BEEPING alarm.
- a. Press Once: 5 Minute Cycle (Blue Light)
  - b. Press Twice: 7 Minute Cycle (Green Light)
  - c. Press Third time: Machine shuts off.
- To Operate:**
1. Press power button twice to start a 7 minute cycle. (GREEN)
  2. After 7 minute cycle ends we recommend repeating this 7 minute cycle again to saturate the H2 level for highest benefit.
  3. Unit Beeps and power shuts off at the end of each timed cycle.
  4. Use 5 minute cycle to keep H2 water fresh while pausing.
  5. Remove bottle cap and drink from bottle within minutes.
  6. Operate on counter top to open bottom Oxygen/Ozone valve.
  7. Drink 4 – 6 bottles or more per day for maximum H2 benefit.



# Advisories



# Quick Start Guide



# Sport MAXX

## Contents

- 1 Bottle Cap
- 2 Glass Bottle
- 3 Rubber Plug (Please Dispose)
- 4 Generator
- 5 Power Switch
- 6 Release Valve
- 7 Waste Chamber Cap

## Accessories

- 8 USB Power Cable/Plug
- 9 Inhaler Adapter/Cannula
- 10 Spare Silicone Washers
- 11 Bottle Adapter Kit
- 12 Generator Cap
- 13 Protective Bottle Sleeve



## Water Bottle Adapter Kit Instructions

Note: Adapter Rings work best on larger bottles over 12 oz size.

1. Place Wide Washer in center rim.
2. Choose a ring that fits Store Bottle.
3. Screw ring in place with notches up.
4. Twist unit on bottle neck like a cap.
5. Flip it over and run gas up into water.
6. Flip back again and remove generator.
7. Use notches to remove ring if on tight.



## Cleaning and Maintenance:

This unit is equipped with a Self-Cleaning mode feature that reverses the polarity of the Plates to produce Ozone gas as an effective cleaner and sterilizer to keep the unit clean and efficient to produce pure hydrogen gas into the water.

## Cleaning Instructions:

1. Attach glass bottle to Generator and fill half full of water.
2. Start a 3 minute Self-Cleaning cycle by pressing and holding down the power button until the light turns purple and it beeps 10 times.
3. Allow 3 minute cycle to complete and shut off automatically and then dispose of this water and rinse out before using.

## Cleaning Frequency:

If you drink purified filtered water, run cleaning cycle once a month. If you drink unfiltered tap water, run cleaning cycle once a week.

**WARNING:** ALWAYS DISPOSE OF WATER AND RINSE OUT THOROUGHLY AFTER CLEANING CYCLE IS FINISHED.

## Inhaler Adapter Instructions

Note: Inhaling is a water substitute when drinking isn't practical. Use for plane and car trips or evenings. Always drink when possible.

1. Attach open end of tube onto protruding pipe in center of round bottle Adapter.
2. Fill bottle 3/4 full of water and cap with Adapter lid.
3. Put tube loop over head and prongs into nostrils and adjust slack-bead behind neck.



4. Press 7 min timer cycle and inhale. Repeat at will for 30 – 60 minutes or longer.

## H2 USB SPORT MAXX SPECIFICATIONS

POWER SUPPLY	USB 5V/ 110 – 230 VLT
BOTTLE CAPACITY	14 OZ / 400 ml (GLASS)
WATER REQUIRED	FOR ALL WATER TYPES
HYDROGEN PPM	0.8~1.0 (5 min) / 1.0~1.5 (7 min)
CLEANING TYPE	OZONE GAS
ORP RANGE	-350mv ~ -650mv